

FAST THIMBLE for



FAST FX+ INSTRUCTIONS













| FAST ASYMMETRIC SPINNAKER THIMBLE | | | | | |
|-----------------------------------|---------------------|----------------------|----------------|---------------|-------------|
| Model | FX/FX+/FXT Model | Jaw width (mm) | Height (mm) | Weight (g) | Reference |
| FAST 1500 | 1500 | 15 | 65 | 222 | 43230001540 |
| FAST 2500 | 2500 | 17,5 | 82 | 426 | 43230002540 |
| FAST 4500 | 4500 | 19 | 92 | 581 | 43230004540 |
| FAST 7000 | 7000 | 26 | 119 | 1114 | 43230007040 |
| FAST 12000 | Please contact us | | | | |
| Custom | | | | | |

anti-twist rope

(on request)

FROM GENNAKER TO ASYMMETRIC SPINNAKER

FAST thimble adjusted to the jaws of the FX+/FX/FXT models

- Captive quick release pin

- Rotating tack fitting with Torlon® balls

Safe tack attachment

Tack attaching rope included



- with the Fast adapter, the antitwist rope rotates up to the top and then transmits the rotation from the head to the tack of sail

> (Sail furls in from head to tack

(See FX+ Gennaker and Code zero furler instructions)





tape)

inside the luff



Ref. 29160040105 ind. A





2. ASYMMETRIC SPINNAKER ATTACHMENT










USE INSTRUCTIONS

1. TOP-DOWN FURLING:



2. USE PRECAUTIONS

- The preparation and the hoisting precautions are the same as for the FX+ Gennaker furlers (see corresponding instructions);
- At the beginning of the handling, check that anything prevents the head of the sail from free furling;
- In light air, if necessary increase the pressure in the sail by slightly sailing upwind.



Always check if anything prevents the head of the sail from free furling.

3. MAINTENANCE:

- Rinse the mechanisms after use.



Please do not hesitate to contact Facnor sales team (info@facnor.com) or agents if you have any queries : info@facnor.com